MID BACK

COVER KIT - INSTALLATION GUIDE

CONVOY SERIES™



1 Remove arms according to your seat instructions. If no arms are present, move to Step 2.



2 Slide the cover over the upper portion of the seat, making sure the document pocket is aligned on the back of the Seat.





3 Pull lower portion of the cover down around the seat cushion ensuring the elastic is fully under the seat cushion and not sitting on the edge





4 Fasten buckle behind seat in desired position and cinch strap until tight to create a sung fit.





5 Reinstall your seat arms according to your seat instructions.

#350110CK
#350111CK
#350115CK

HIGH BACK
COVER KIT - INSTALLATION GUIDE

CONVOY SERIES™





1 Remove arms & headrest according to your seat instructions. If no arms are present, move to Step 3A.



2 Slide the headrest cover over your existing headrest, tuck in and secure the velcro tabs. Set aside while you install the back cover.



3A Pull lower portion of the cover down around the seat cushion ensuring the elastic is fully under the seat cushion and not sitting on the edge

3B Place the unturned portion of the cover over the top of the upper area of your seat back and start rolling/pulling it down over your seat. Making sure to adjust and align your seams along the way.







4 On the front portion of the back cover push the velcro strip through the gap between back of the seat and seat cushion. Pull tight and secure velcro edges together.

#350101CK
#350106CK
#350131CK

HIGH BACK
SEAT COVER KIT - INSTALLATION GUIDE

CONVOY SERIES™



5 Reinstall your seat arms and headrest according to your seat instructions.



6 Slip the seat cover over your seat cushion. Push the back of the cover with the elastic cord loops through the gap between the back of the seat and seat cushion.



7 Pull the elastic cord with “S” hook around each side of the seat and secure to the elastic loop that you pushed through previously.



Note: If you find the lower portion of your seat cover loose after installation you may need to tighten the elastic cord with the "S" hooks. To do this, simply untie the knot that holds the "S" hook in place and slide further down the cord and re-tie the knot.

#350101CK
#350106CK
#350131CK