CONVOY II OPERATIONAL GUIDE

12 VOLT

APPLIES TO ALL CONVOY II MODELS





Manual Air Height Adjustment

(Pull Lever UP ▲ to Turn on Compressor, Pull Down ▼ to Lower)

